



Installation and Maintenance Manual

5 Port Solenoid Valve, Series VQC



Read this manual before using this product

- The information within this document is to be used by pneumatically trained personnel only.
- For future reference, please keep manual in a safe place.
- This manual should be read in conjunction with the current catalogue.

1 SAFETY RECOMMENDATION

1.1 General recommendation

These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by label of "Caution", "Warning" or "Danger". To ensure safety, be sure to observe ISO4414 (Note1), JIS B 8370 (Note2) and other safety practices.

Note 1:ISO 4414:Pneumatic fluid power - General rules relating to systems.
 Note 2:JIS B 8370:Pneumatic system axiom.

CAUTION: Operator error could result in injury or equipment damage.

WARNING: Operator error could result in serious injury or loss of life.

DANGER: In extreme conditions, there is a possible result of serious injury or loss of life.

- WARNING:**
- The compatibility of pneumatic equipment is the responsibility of the person who designs the pneumatic system or decides its specifications.
 - Since the products specified here are used in various operating conditions, their compatibility for the specific pneumatic system must be based on specifications or after analysis and/or tests to meet your specific requirements.
 - Only trained personnel should operate pneumatically operated machinery and equipment.
 - Compressed air can be dangerous if an operator is unfamiliar with it Assembly, handling or repair of pneumatic systems should be performed by trained and experienced operators.
 - Do not service machinery/equipment or attempt to remove component until safety is confirmed.
 - Inspection and maintenance of machinery/equipment should only be performed after confirmation of safe locked-out control positions.
 - When equipment is to be removed, confirm the safety process as mentioned above. Switch off air and electrical supplies and exhaust all residual compressed air in the system.
 - Before machinery/equipment is re-started, ensure all safety measures to prevent sudden movement of cylinders etc. (Bleed air into the system gradually to create backpressure, i.e. incorporate a soft-start valve).
 - Contact SMC if the product is to be used in any of the following conditions:
 - Conditions and environments beyond the given specifications, or if product is used outdoors.
 - Installations in conjunction with atomic energy, railway, air navigation, vehicles, medical equipment, food and beverage, recreation equipment, emergency stop circuits, press applications, or safety equipment.
 - An application, which has the possibility of having negative effects on people, property, or animals, requiring special safety analysis.

CAUTION:

- Ensure that the air supply system is filtered to 5 micron.

1.2 Conformity to standard

This product is certified to and complies with the following standards:

EMC Directive 89/336/EEC	EN61000-6-2, EN55011, EN61000-4-5
--------------------------	-----------------------------------


2 INTENDED CONDITIONS OF USE

2.1 Specifications


Valve specification	Valve Configuration		Metal seal	Rubber seal
	Fluid		Air/Inert gas	
VQC1000/2000	Max. operating pressure	Single	0.7MPa (High pressure type: 1.0MPa) (Note 4)	0.15MPa
		Double	0.1MPa	0.1MPa
		3-position	0.1MPa	0.2MPa
		4-position	-	0.15MPa
VQC4000	Max. operating pressure (Note 3)	Single	1.0MPa (0.7MPa)	
		Double	0.15MPa	0.2MPa
		3-position	0.15MPa	0.2MPa
		4-position	-	0.15MPa
Electrical specification	Proof pressure		1.5MPa	
	Ambient and fluid temperature		-10° to 50°C (Note 1)	
	Lubrication		Not required	
	Manual override		Push type/Locking type (tool required) optional	
	Impact resistance/Vibration resistance		150/30 m/s ² (Note 2)	
	Enclosure		IP67	
	Rated coil voltage		12VDC, 24VDC	
	Allowable voltage fluctuation		±10% of rated voltage	
	Coil insulation type		Equivalent to B type	
	Power consumption (current)	24VDC	1W DC (42mA), 0.5W DC (21mA)	
12VDC			1W DC (83mA), 0.5W DC (42mA)	

- (Note 1) Use dry air to prevent condensation at low temperatures.
- (Note 2) Impact resistance: No malfunction resulted from the impact test using a drop impact tester. The test was performed one time each in the axial and right angle directions of the main valve and armature, for both energized and de-energized states.
- Vibration resistance: No malfunction occurred in a one-sweep test between 8.3 and 2000Hz. Test was performed in the axial and right angle directions of the main valve and armature for both energized and de-energized states.
- (Note 3) Values in () are for the low wattage (0.5W) specification.
- (Note 4) Metal seal type only.

2.2 Piping



2.3 Circuit Symbols



3 INSTALLATION

WARNING:

- Do not install unless the safety instructions have been read and understood.

3.1 Environment

- WARNING:**
- Do not use in an environment where the product is directly exposed to corrosive gases, chemicals, salt water, water or steam.
 - Do not use in an explosive atmosphere.
 - The product should not be exposed to prolonged sunlight. Use a protective cover.
 - Do not mount the product in a location where it is subject to strong vibrations and/or shock. Check the product specifications for above ratings.
 - Do not mount the product in a location where it is exposed to radiant heat.

3.2 Piping

- CAUTION:**
- Before piping make sure to clean up chips, cutting oil, dust etc.
 - When installing piping or fitting into a port, ensure that sealant material does not enter the port inside. When using seal tape, leave 1.5 to 2 threads exposed on the end of pipe/fitting.

Thread	Appropriate tightening torque (Nm)
Rc(PT) 1/8	7 to 9
Rc(PT) 1/4	12 to 14
Rc(PT) 3/8	22 to 24
Rc(PT) 1/2	28 to 30
Rc(PT) 3/4	28 to 30

3.3 Electrical connection


- CAUTION:**
- When DC power is connected to a solenoid valve equipped with light and/or surge voltage suppressor, check for polarity indications.
 - For polarity indications:
 - No diode to protect polarity: if polarity connection is wrong, the diode in the valve or switching device at control equipment or power supply may be damaged.
 - With diode to protect polarity: if polarity connection is wrong, the valve does not switch.

3.3.2 Cable safety instructions

- Avoid miswiring, as this can cause malfunction, damage and fire in the unit.
- To prevent noise and surge in signal lines, keep all wiring separate from power lines and high voltage lines. Otherwise, this can cause a malfunction.
- Check wiring insulation, as defective insulation can cause damage to the unit when excessive voltage or current is applied.
- Do not bend or pull cables repeatedly, and do not place heavy objects on them or allow them to be pinched. This can cause broken


3.3.3 Light/Surge voltage suppressor VQC1000/2000

Indicator lights are all positioned on one side for both single solenoid and double solenoid type valves.
 For double solenoid type, 2 colors that are same as the manual override are used to indicate the energization of A-side or B-side.




3.3.4 Internal wiring specification

VQC1000/2000



VQC4000



3.3.5 Electrical Wiring

D-sub connector

As the standard electrical wiring specification used as for 12 stations or less, double wiring (connected to SOL A and SOL B) is used for the internal wiring of each station regardless of valve and option types. Mixed single and double wiring are available as options. Refer to special wiring specifications (options) below.

Lead wire colors for D-sub connector assemblies (AXT100-DS25-001)

Terminal no.	Polarity	Lead wire color	Dot marking
Station 1	SOL_A 1 (-)	Black	None
	SOL_B 14 (-)	Yellow	Black
Station 2	SOL_A 2 (-)	Brown	None
	SOL_B 15 (-)	Pink	Black
Station 3	SOL_A 3 (-)	Red	None
	SOL_B 16 (-)	Blue	White
Station 4	SOL_A 4 (-)	Orange	None
	SOL_B 17 (-)	Purple	None
Station 5	SOL_A 5 (-)	Yellow	None
	SOL_B 18 (-)	Gray	None
Station 6	SOL_A 6 (-)	Pink	None
	SOL_B 19 (-)	Orange	Black
Station 7	SOL_A 7 (-)	Blue	None
	SOL_B 20 (-)	Red	White
Station 8	SOL_A 8 (-)	Purple	White
	SOL_B 21 (-)	Brown	White
Station 9	SOL_A 9 (-)	Gray	Black
	SOL_B 22 (-)	Pink	Red
Station 10	SOL_A 10 (-)	White	Black
	SOL_B 23 (-)	Gray	Red
Station 11	SOL_A 11 (-)	White	Red
	SOL_B 24 (-)	Black	White
Station 12	SOL_A 12 (-)	Yellow	Red
	SOL_B 25 (-)	White	None
	COM + 13 (+)	Orange	Red

Note) When using the negative COM specification, use valves for negative COM.

Flat ribbon cable connector

Double wiring (connected to SOL A and SOL B) is used for the internal wiring of each station regardless of valve and option types. Mixed single and double wiring are available as options. Refer to special wiring specifications (options) below.



Connector terminal number

Triangle mark indicator position

Terminal no.	Polarity	Terminal no.	Polarity
Station 1	SOL_A 1 (-)	Station 1	SOL_B 2 (-)
	SOL_B 2 (-)	Station 2	SOL_A 3 (-)
Station 2	SOL_A 3 (-)		SOL_B 4 (-)
	SOL_B 4 (-)	Station 3	SOL_A 5 (-)
Station 3	SOL_A 5 (-)		SOL_B 6 (-)
	SOL_B 6 (-)	Station 4	SOL_A 7 (-)
Station 4	SOL_A 7 (-)		SOL_B 8 (-)
	SOL_B 8 (-)	Station 5	SOL_A 9 (-)
Station 5	SOL_A 9 (-)		SOL_B 10 (-)
	SOL_B 10 (-)	Station 6	SOL_A 11 (-)
Station 6	SOL_A 11 (-)		SOL_B 12 (-)
	SOL_B 12 (-)	Station 7	SOL_A 13 (-)
Station 7	SOL_A 13 (-)		SOL_B 14 (-)
	SOL_B 14 (-)	Station 8	SOL_A 15 (-)
Station 8	SOL_A 15 (-)		SOL_B 16 (-)
	SOL_B 16 (-)	Station 9	SOL_A 17 (-)
Station 9	SOL_A 17 (-)		SOL_B 18 (-)
	SOL_B 18 (-)	Station 10	SOL_A 19 (-)
Station 10	SOL_A 19 (-)		COM - 19 (-)
	SOL_B 20 (-)	Station 11	SOL_A 21 (-)
Station 11	SOL_A 21 (-)		COM - 20 (-)
	SOL_B 22 (-)	Station 12	SOL_A 23 (-)
Station 12	SOL_A 23 (-)		COM - 21 (-)
	SOL_B 24 (-)		COM - 22 (-)
	COM + 25 (+)		COM - 23 (-)
	COM + 26 (+)		COM - 24 (-)

Note) When using the negative COM specification, use valves for negative COM.

Terminal box kit (T kit)



Multi connector kit (M kit)

Multiple connector

Double wiring/connected to SOLA and SOLB is used for the internal wiring of each station regardless of valve and option types. Mixed single and double wiring are available as options. Refer to special wiring specifications/options below.

Terminal no.	Polarity	Station
SOL_A_1	(+)	(+)
SOL_B_1	(-)	(-)
SOL_A_2	(+)	(+)
SOL_B_2	(-)	(-)
SOL_A_3	(+)	(+)
SOL_B_3	(-)	(-)
SOL_A_4	(+)	(+)
SOL_B_4	(-)	(-)
SOL_A_5	(+)	(+)
SOL_B_5	(-)	(-)
SOL_A_6	(+)	(+)
SOL_B_6	(-)	(-)
SOL_A_7	(+)	(+)
SOL_B_7	(-)	(-)
SOL_A_8	(+)	(+)
SOL_B_8	(-)	(-)
SOL_A_9	(+)	(+)
SOL_B_9	(-)	(-)
SOL_A_10	(+)	(+)
SOL_B_10	(-)	(-)
SOL_A_11	(+)	(+)
SOL_B_11	(-)	(-)
SOL_A_12	(+)	(+)
SOL_B_12	(-)	(-)
SOL_A_13	(+)	(+)
SOL_B_13	(-)	(-)
SOL_A_14	(+)	(+)
SOL_B_14	(-)	(-)
SOL_A_15	(+)	(+)
SOL_B_15	(-)	(-)
SOL_A_16	(+)	(+)
SOL_B_16	(-)	(-)
SOL_A_17	(+)	(+)
SOL_B_17	(-)	(-)
SOL_A_18	(+)	(+)
SOL_B_18	(-)	(-)
SOL_A_19	(+)	(+)
SOL_B_19	(-)	(-)
SOL_A_20	(+)	(+)
SOL_B_20	(-)	(-)
SOL_A_21	(+)	(+)
SOL_B_21	(-)	(-)
SOL_A_22	(+)	(+)
SOL_B_22	(-)	(-)
SOL_A_23	(+)	(+)
SOL_B_23	(-)	(-)
SOL_A_24	(+)	(+)
SOL_B_24	(-)	(-)
COM_φ25	(+)	(+)
COM_φ26	(-)	(-)

Terminal Polarity Station

Lead wire colours according to pin numbers
The colour code is according to DIN47100.

Pin no.	Lead wire identification
1	white
2	brown
3	green
4	yellow
5	gray
6	pink
7	blue
8	red
9	black
10	violet
11	gray
12	red
13	white
14	brown
15	white
16	yellow
17	white
18	gray
19	white
20	pink
21	white
22	brown
23	white
24	brown
25	white
26	bridged to pin 25

Connector pin number (Arrangement as seen from the cable's port side)

Electrical characteristics

Item	Characteristics
Conductor resistance Ω/m, 20°C	57 or less
Electric strength V, 5min, AC	1500
Insulation resistance MΩ/m	20

(See also AXT100-MC26-015 which conforms to colour code MIL-C-24308)
* For detailed specifications and handling, please contact SMC.

Note: When using the negative COM specification for VQC1000/2000, use values for negative COM.

Lead wire cable kit (L kit)

Lead wire 0.3mm² × 25mm

As the standard electrical wiring specification used is for 12 stations or less, double wiring connected to SOLA and SOLB is used for the internal wiring of each station regardless of valve and option types. Mixed single and double wiring are available as options. Refer to special wiring specifications (options) below.

Terminal no.	Polarity	Lead wire color	Dot marking
SOL_A_1	(+)	Black	None
SOL_B_1	(-)	Yellow	Black
SOL_A_2	(+)	Brown	None
SOL_B_2	(-)	Pink	Black
SOL_A_3	(+)	Red	None
SOL_B_3	(-)	Blue	White
SOL_A_4	(+)	Orange	None
SOL_B_4	(-)	Purple	None
SOL_A_5	(+)	Yellow	None
SOL_B_5	(-)	Gray	None
SOL_A_6	(+)	Orange	None
SOL_B_6	(-)	Orange	Black
SOL_A_7	(+)	Blue	None
SOL_B_7	(-)	Red	White
SOL_A_8	(+)	Purple	White
SOL_B_8	(-)	Pink	White
SOL_A_9	(+)	Gray	Black
SOL_B_9	(-)	Gray	Black
SOL_A_10	(+)	Pink	Red
SOL_B_10	(-)	White	Black
SOL_A_11	(+)	Gray	Red
SOL_B_11	(-)	White	Red
SOL_A_12	(+)	Black	White
SOL_B_12	(-)	White	Red
COM_φ13	(+)	Orange	Red

Note: When using the negative COM specification for VQC1000/2000, use values for negative COM.

3.4 Mounting

- If air leakage increases or equipment does not operate properly, stop operation.**
After mounting, repairs, or equipment modification, connect the compressed air and power supplies, and perform appropriate function and leakage inspections to confirm that the unit is mounted properly.
- Instruction manual**
Mount and operate the product only after reading the manual carefully and understanding its contents. Always keep the manual handy for easy reference.
- Painting and coating**
Warnings or specifications printed or pasted on the product should not be erased, removed or covered up.

Solenoid valve removal and mounting VQC1000/2000


- Loosen the clamp screws until they turn freely. (The screws do not come out.)
- Remove the solenoid valve from clamp B by lifting the coil side of the valve while pushing on the screw top. If pushing down on the screw is difficult, you can alternately press down on the valve gently in the area near the manual override.

Mounting steps

- Push the clamp screws. Clamp A opens. Now insert the end plate hook of the valve into clamp B from an angle.
- Push the valve down into place. (When you release the screws, the valve will be locked into clamp A.)
- Tighten the clamp screws with a tightening torque of 0.25 to 0.35N·m for VQC1000 and 0.5 to 0.7N·m for VQC2000.


CAUTION:

Do not let foreign matter stick on the seal side of the gasket and solenoid, as this will cause air leakage.



Valve mounting VQC4000

After confirming that the gasket is installed correctly, securely tighten the mounting screws according to the tightening torque shown below.



3.5 Lubrication

CAUTION:

- SMC products have been lubricated for life at manufacturer, and do not require lubrication in service.
- If a lubricant is used in the system, use turbine oil Class 1 (no additive), ISO VG32. Once lubricant is used in the system, lubrication must be continued because the original lubricant applied during manufacturing will be washed away.

- The valve has been lubricated for life at the factory, and does not require any further lubrication.
- Should you wish to apply additional lubrication, however, please be sure to use ISO VG32 Class 1 turbine oil (without additives). Please be aware, however, that once additional lubrication is applied, it must be continued to avoid malfunctions, as the new lubricant will completely cancel out the original lubrication.


4 SETTINGS AND PROGRAMMING

Manual override


Since connected equipment will operate when the manual override is activated, confirm that conditions are safe prior to activation. The non-locking push type (tool required) is standard, and the slotted locking type (tool required) is optional.

VQC1000/2000


Non-locking push type (tool required)



Slotted locking type (tool required) <Optional>




Locking type (manual) <Optional>




VQC4000

Non-locking push type (tool required)



Push down the manual override button with a small screwdriver until it stops. The manual override will return when released.

Locking type (manual) <Optional>



Push down the manual override button with a small flat head screwdriver until it stops, and turn it clockwise 90° to lock it. Turn it counterclockwise to release it.

5 MAINTENANCE

WARNING:

- Not following proper procedures could cause the product to malfunction and could lead to damage to the equipment or machine.
- If handled improperly, compressed air can be dangerous. Assembly, handling and repair of pneumatic system should be performed by qualified personnel only.
- Drain: remove condensate from the filter bowl on a regular basis.
- Shut-down before maintenance: before attempting any kind of maintenance make sure the supply pressure is shut off and all residual air pressure is released from the system to be worked on.
- Start-up after maintenance: apply operating pressure and power to the equipment and check for proper operation and possible air leaks. If operation is abnormal, please verify product set-up parameters.
- Do not make any modification to the product.
- Do not disassemble the product, unless required by installation or maintenance instructions.

- Perform maintenance procedures as shown in the instruction manual.**
If handled improperly, malfunction or damage of machinery or equipment may occur.
- Equipment removal and supply/exhaust of compressed air**
When equipment is to be removed, first confirm that measures are in place to prevent dropping of driven objects and run-away of equipment, etc. Then cut the supply air pressure and electric power, and exhaust all compressed air from the system using its residual pressure release function.
- Infrequent operation**
Valves should be switched at least once every 30 days to prevent malfunction. (Use caution regarding the air supply.)
- Manual override operation**
When the manual override is operated, connected equipment will be actuated. Confirm safety before operating.

Replacing one-touch fittings

- Cylinder port fittings are available in cassette type and can be replaced easily.
- Fittings are secured with a retaining clip that is inserted from the top side of the valve. After removing the valve, remove the clip with a flat head screw driver to replace the fittings.
- To mount a fitting, insert the fitting assembly until it stops and reinsert the retaining clip to its designated position.

VQC1000/2000

Applicable tube O.D.	Fitting assembly part no.	
	VQC1000	VQC2000
φ3.2	VVQ1000-50A-C3	—
φ4	VVQ1000-50A-C4	VVQ1000-51A-C4
φ6	VVQ1000-50A-C6	VVQ1000-51A-C6
φ8	—	VVQ1000-51A-C8
M5	VVQ1000-50A-M5	—
φ18*	VVQ1000-50A-N1	—
φ32*	VVQ1000-50A-N3	VVQ1000-51A-N3
φ18*	VVQ1000-50A-N7	VVQ1000-51A-N7
φ16*	—	VVQ1000-51A-N6

VQC4000

Applicable tube O.D.	Fitting assembly part no.
—	VQC4000
φ8	VVQ4000-50B-C8
φ10	VVQ4000-50B-C10
φ12	VVQ4000-50B-C12
φ14*	VVQ4000-50B-N7
φ516*	VVQ4000-50B-N9
φ38*	VVQ4000-50B-N11

6 LIMITATIONS OF USE

WARNING:

- Do not exceed any of the specifications laid out in section 2 of this document or the specific product catalogue.

- Confirm all specifications.**
The products featured in this catalog are designed only for use in compressed air systems (including vacuum). Do not operate at pressures or temperatures beyond the range of specifications, as this can cause damage or malfunction. (Refer to specifications.) Contact SMC when using a fluid other than compressed air (including vacuum).
- Extended periods of continuous en-ergization**
Contact SMC if valves will be continuously energized for extended periods of time.

CAUTION:

- Momentary en-ergization**
If a double solenoid valve will be operated with momentary en-ergization, it should be energized for at least 0.1 second. However, depending on the secondary load conditions, it should be energized until the cylinder reaches the stroke end position. If the valve is to be used in an air blowing application, it should be energized continuously during the application.
- Leakage voltage**
When using a C-R element (surge voltage suppressor) for protection of the switching element, please keep in mind that leakage voltage will increase due to leakage current flowing through the C-R element.

Limit the amount of residual leakage voltage to the following values:
With DC coil 2% or less of rated voltage

- Low temperature operation**
Avoid ambient temperatures outside the range of -10°C to 50°C. At low temperatures, take any necessary steps to avoid solidification or freezing of drainage and moisture.
- For air blowing applications**
When using solenoid valves for air blowing, use external pilot type valves. Also, air supply to the external pilot port should be compressed air that is within the pressure range prescribed in the specifications.
- Mounting orientation**
In the case of a single solenoid, the mounting orientation is unrestricted. In the case of double solenoid or 3-position valves, mount so that the spool valve is horizontal. Also, when mounting for an application that will inevitably involve vibration or impact, mount so that the spool valve is at a right angle to the direction of vibration. Do not use in applications where vibration or impact exceed the product's specifications.

7 EUROPEAN CONTACT LIST

7.1 SMC Corporation

Country	Telephone	Country	Telephone
Austria	(43) 2262-62 280	Italy	(39) 02-92711
Belgium	(32) 3-355 1464	Netherlands	(31) 20-531 8888
Czech Republic	(420) 5-414 24611	Norway	(47) 67 12 90 20
Denmark	(45) 70 25 29 00	Poland	(48) 22-548 50 85
Finland	(358) 9-859 580	Portugal	(351) 22 610 89 22
France	(33) 1-64 76 1000	Spain	(34) 945-18 4100
Germany	(49) 6103 4020	Sweden	(46) 8 603 12 00
Greece	(30) 1- 342 6076	Switzerland	(41) 52-396 3131
Hungary	(36) 23 511 390	Turkey	(90) 212 221 1512
Ireland	(353) 1-403 9000	United Kingdom	(44) 1908-56 3888

7.2 Websites

SMC Corporation	www.smcworld.com
SMC Europe	www.smceu.com